instdrg-M352b.ai
B
C
E
F
F
G
D
B
H
A
Copyright 2017 © Avalanche Ranch Light Company962-M352-b.indd/revised 4/6/17
Page 1 of 2
PO Box 31397
Bellingham, WA 98228-3397
(t) 360-752-1610
(f) 360-752-1612
INSTALLATION INSTRUCTIONS
HW KIT # 94-M352
1.Following Diagram 1, hold mounting plate (B) to the wall with the large center hole over the junction box. Make sure the mounting plate is level with the floor. Mark wall through open slot on top and bottom on both sides. Remove mounting plate.2.Screw plastic anchors (C) into the wall at the marks. 3.Place mounting plate (B) flush to wall with open slots over plastic anchors (C). Insert machine screws (D) through mounting plate (B) and tighten into plastic anchors (C). Be sure mounting plate is secure. 4.Insert the ¾” threaded pipes (F) into each of the nuts, attached to the mounting plate (B).5.Following Diagram 2, attach the lantern to the top of the fixture (A) using a die cast ring.PARTS LIST A.Assembled Fixture (1)B.Mounting Plate (1)C.Plastic Anchors (2)D.1” Machine Screws (2)E.Wire Connectors (3)F.¾” Threaded Pipe (2)G.Rustic Cap Nut (2)H.Arm and Back Plate (1)DIAGRAM 1DIAGRAM 2GENERAL1.To ensure the success of the installation, be sure to read these instructions and review the diagrams thoroughly before begin-
ning.2.All electrical connections must be in accordance with local codes, ordinances, or the National Electrical Code. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified licensed electrician.3.These fixtures are intended to be mounted to a minimum 4” x 1-1/8” deep round outlet box. The box must be directly support-
ed by the building structure.4.Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock.NOTE: The important safeguards and instructions appearing in these instructions are not meant to cover all possible condi-
tions and situations that may occur. It must be understood that common sense, caution, and care are factors, which cannot be built into any product. These factors must be supplied by the person(s) caring for and operating the fixture.instdrg-M352b.aiB
C
E
F
G
D
B
H
A
THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Avalanche Ranch Light Company’s liability under any warranty, whether express or implied, is LIMITED SOLELY TO THE REPAIR OR REPLACEMENT OF THE DEFECTIVE PRODUCT FOR THE DURATION OF THIS WARRANTY AND DOES NOT INCLUDE LABOR OR OTHER CONSEQUENTIAL OR INCIDENTAL DAMAGES.LIMITED 2-YEAR WARRANTY: Avalanche Ranch Light Company warrants that its products are free of defects in workmanship and materials for a period of two years from date of purchase. If within two years from date of purchase any of its products are found defective in workmanship or materials, Avalanche Ranch Light Company will repair or replace, at its sole option, the defective product upon presentation of proof of purchase and the defective product. 6.Complete step 5 for remaining hanging units.7.Hold the assembled xture (A) up to mounting plate (B). Using wire connectors (E), connect the white supply wire to the white xture wire and connect the black supply wire to the black xture wire. Then connect the ground wire from the xture to the ground wire in the junction box. Be sure no bare wires are exposed outside the wire connectors. 8.Tuck the excess wires back into the junction box.Place the lip on the back of the arm and back plate (H) over the top edge of the mounting plate (B). Align the ¾” threaded pipe (F) through the hole in the back plate. Secure xture using the rustic cap nut (G).9.Electricity may now be restored to the xture.WIRING AND INSTALLATION