

PO Box 31517  
BELLINGHAM, WA 98228-3517  
(T) 360-752-2989 • 888-520-7046  
(F) 360-255-2172 • 888-520-7048

**ROCKY MTN FLOOR LAMP**

**HW KIT # 94-M626**

**GENERAL**

- 1. To ensure the success of the installation, be sure to read these instructions and review the diagrams thoroughly before beginning.
- 2. All electrical connections must be in accordance with local codes, ordinances, or the National Electrical Code. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified licensed electrician.

NOTE: The important safeguards and instructions appear

**ASSEMBLY**

- 1. Disconnect the bottom plate (A) from the lower cover (B) by removing the feet (C).
- 2. Slip the cord set through the hole in the lower cover (B) and then through the hole in the bottom plate (A).
- 3. Slide the lower cover (B) up the lamp tube (E) and secure the lamp tube (E) to the bottom plate (A) by tightening the hex bolts (F).
- 4. Slide the lower cover (B) back down the lamp tube (E) and reattach it to the bottom plate (A) using the feet (C).
- 5. The feet (C) may be adjustable for different floors. Do this by loosening the nut on the foot and threading the threaded pipe in or out depending on adjustment. Once level, tighten nut to the bottom plate (A) to hold height.

