




#### PARTS LIST - SECTION B

- A. Fixture Base
- B. Glass
- C. Image Set
- D. Metal Ring
- E. Die Cast Ring

#### SECTION B - ASSEMBLY INSTRUCTIONS

1. Slide image set (C) up onto the fixture base (A).
2. Slide the glass (B) and metal ring (D) inside the image set (C) until it stops.
3. Secure glass (B), image set (C), and metal ring (D) with die cast ring (E).
4. Electricity may now be restored.



**LIMITED 2-YEAR WARRANTY:** Avalanche Ranch Light Company warrants that its products are free of defects in workmanship and materials for a period of two years from date of purchase. If within two years from date of purchase any of its products are found defective in workmanship or materials, Avalanche Ranch Light Company will repair or replace, at its sole option, the defective product upon presentation of proof of purchase and the defective product.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Avalanche Ranch Light Company's liability under any warranty, whether express or implied, is LIMITED SOLELY TO THE REPAIR OR REPLACEMENT OF THE DEFECTIVE PRODUCT FOR THE DURATION OF THIS WARRANTY AND DOES NOT INCLUDE LABOR OR OTHER CONSEQUENTIAL OR INCIDENTAL DAMAGES.