


PO Box 31517
 BELLINGHAM, WA 98228-3517
 (T) 360-752-2989 • 888-520-7046
 (F) 360-255-2172 • 888-520-7048

PARTS LIST

- A. Cross Bar
- B. 1" or 1/2" Screws (2)
- C. Green Ground Screw
- D. Wire Connectors (2)
- E. Threaded Pipe
- F. Cap Nut
- G. Glass
- H. Die Cast Ring
- I. Acorn nuts (2)
- J. Cover Plate



GENERAL

1. To ensure the success of the installation, be sure to read these instructions and review the diagrams thoroughly before beginning.
2. All electrical connections must be in accordance with local codes, ordinances, or the National Electrical Code. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified licensed electrician.
3. These fixtures are intended to be mounted to a minimum 4" x 1-1/8" deep round outlet box. The box must be directly supported by the building structure.
4. **Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock.**

NOTE:The important safeguards and instructions appearing in these instructions are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care are factors, which cannot be built into any product. These factors must be supplied by the person(s) caring for and operating the fixture.

WIRING & INSTALLATION

1. Pull power supply wires out of junction box.
2. Fasten cross bar (A) to junction box using 1" or 1/2" screws (B). Be sure cross bar is flush with wall.
3. Wrap green ground wire from junction box around green ground screw (C) in clockwise direction and thread into cross bar (A).
4. Using the wire connectors (D), connect the white supply wire to the white fixture wire and connect the black supply wire to black fixture wire. Be sure no bare wires are exposed outside of wire connectors.
5. Thread the threaded pipe (E) into the rustic cap nut (F) and tighten.
6. Place the base of the fixture over junction box with the center mounting hole aligned with the center of the cross bar. Insert the threaded pipe and cap nut assembly through the center hole of the fixture and thread into cross bar until secure.
7. Use the appropriate exterior rated silicone to seal around the top and sides of the fixture base.
8. After the fixture base is securely attached to the wall, secure the glass (G) by placing it over the socket and securing the white die cast ring (H) inside the glass.
9. Take the cover plate (J) and lift the rear of the cover plate behind the glass and slip the threaded stud on the fixture base through the holes in the rear of the cover plate. Secure using the acorn nuts (I) provided.
10. Electricity may now be restored to the fixture.

LIMITED 2-YEAR WARRANTY: Mountain Ranch Lighting warrants that its products are free of defects in workmanship and materials for a period of two years from date of purchase. If within two years from date of purchase any of its products are found defective in workmanship or materials, Mountain Ranch Lighting will repair or replace, at its sole option, the defective product upon presentation of proof of purchase and the defective product.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Mountain Ranch Lighting's liability under any warranty, whether express or implied, is LIMITED SOLELY TO THE REPAIR OR REPLACEMENT OF THE DEFECTIVE PRODUCT FOR THE DURATION OF THIS WARRANTY AND DOES NOT INCLUDE LABOR OR OTHER CONSEQUENTIAL OR INCIDENTAL DAMAGES.